

tesa® 51132

Surface protection film

tesa® 51132 is a self adhesive film that has been developed for the protection of various surfaces, especially interior parts of automobiles like carpets, dashboards and door sills during storage, assembly and transportation.

tesa® 51132 consists of a PE backing coated with an water based acrylic adhesive.

Main Application

- Protection of various surfaces against dirt and damage

Technical Data

Backing material	PE film	Adhesion to steel	2.8 N/cm
Total thickness	85 µm	Elongation at break	250 %
Type of adhesive	acrylic	Tensile strength	15 N/cm

Properties

- Easy to remove yes
- Scratch resistance ● ● ●

Evaluation across relevant tesa® assortment: ● ● ● ● very good ● ● ● good ● ● medium ● low

Additional Information

User benefits:

- Cost saving due to reduction in rectification and final repair
- No special equipment needed, ensuring simple, low cost application and removal processes
- Good adhesion to the range of different surfaces like PP, ABS, textile.
- Easy disposal. Both film and adhesive system are environmentally friendly

For latest information on this product please visit <http://l.tesa.com/?ip=51132>

tesa® products prove their impressive quality day in, day out in demanding conditions and are regularly subjected to strict controls. All technical information and data above mentioned are provided to the best of our knowledge on the basis of our practical experience. They shall be considered as average values and are not appropriate for a specification. Therefore tesa SE can make no warranties, expressed or implied, including, but not limited to any implied warranty of merchantability or fitness for a particular purpose. The user is responsible for determining whether the tesa® product is fit for a particular purpose and suitable for the user's method of application. If you are in any doubt, our technical support staff will be glad to support you.